

# BNC Plug Removal Tool,8"

96-2208

Insertion and Extraction tool for coupling and removing BNC plugs when finger access is difficult.



.